



A BRITISH COMPANY SUPPORTING BRITISH CARS

REAR SEAT BELT FITTING GUIDE

Triumph Stag, Herald, Vitesse, Dolomite & 2000/2500/2.5pi

Part Number: **RS1394** in Black, Beige, Red and Grey

BEFORE STARTING INSTALLATION, PLEASE READ THE SEAT BELT FITTING INSTRUCTINS AS SUPPLIED BY THE SEAT MANUFACTURER

1. Lift hood from stowage compartment to allow access. Remove seat base and backrest. Remove side pockets (MKII only)
2. Raise car and support on axle stands placed under driveshaft section of the trailing arm, remove the wheels. Unscrew the plastic plugs in the centre of the floor plan to reveal 7/16th UNF captive nuts. The threads may require cleaning with 7/6th UNF tap. Mount the centre strap as per manufacturer's instructions.
3. For MKII cars, remove the plastic lug in front of the wheel arch and clean the thread. On some late MKII cars the seat belt mounting point is on the side of the wheel arch. It will therefore be necessary to drill a 7/16th diameter hole on the front of the wheel arch to mount the seatbelt. It will be necessary to use the double angle spacer to mount the inertia part of the seat belt up and forward of the original mounting. Mount the inertia reel as per manufacturer's instructions, with webbing towards the centre of the car. The MKII side panels have cut-outs in the hardboard for the seat belts. It will be necessary to cut and glue back the leathercloth to open the aperture.
4. Refit the side panes passing the seatbelt through the aperture in the side panels.
5. For MKI cars, the inertia part of the seatbelt is fitted directly behind the rear seats against the wheel arch with the seatbelt passing between the side panel and seat back rest. When you are happy with the position drill a 7/16th hole and mount the inertia reel.
6. Refit the seat base and backrest.
7. For the shoulder strap mounting point, remove the shock absorber top mount and push the absorber down. Drill a 7/16th hole 2" down the side of the mount Fit shoulder strap as per manufacturer instructions. Refit absorber and wheels.

Quality Parts and Accessories for



Triumph House, Sleaford Road, Bracebridge Heath, Lincoln LN4 2NA,
- Telephone: 01522 568000 | E-mail: customer.services@rimmerbros.com

www.rimmerbros.com