

DEI Insulation Material

Part Number: RX1473B

#050501	2ft x 21" (3.5 sq ft)
#050502	4ft x 21" (7.0 sq ft)
#050503	4ft x 42" (14.0 sq ft)
#050503-16	10" x 10" (.83 sq ft)

Tools needed:

- Scissors or snips
- Cardboard/poster board to use as a template
- Marker

Note of caution

Wear eye and hand protection when installing all materials.
Use spray adhesive in a well ventilated area.

Overview: Floor & Tunnel Shield II is an extreme heat barrier that blocks heat from the engine, exhaust and road from components, interiors, electrical, wire, hoses & more.

1. Although floor and tunnel shield II will stick to almost anything, we recommend removing dirt, grease, oil, wax etc to improve adhesion.
2. Making a template will aid proper and professional installations. Fig 1
3. Trim floor & tunnel shield II to desired size using a snips or scissors.
4. Removing the backing to expose the adhesive and carefully apply to clean and dry desired area. Fig 2.
5. After floor and tunnel shield II is set in proper location, apply pressure to ensure a strong bond with the installation surface. Fig 3.



Fig 1



Fig 2



Fig 3

QUALITY PARTS AND ACCESSORIES



Triumph House, Sleaford Road, Bracebridge Heath, Lincoln LN4 2NA, England

UK Tel: +44 (0)1522 568000 | USA Tel: 1 855 746 2767 | Fax: +44 (0)1522 567600 | E-mail: sales@rimmerbros.com

www.rimmerbros.com