

DISCOVERY 1 / 2 / TD5 / CLASSIC RANGE ROVER

SIDESTEP FITTING INSTRUCTIONS (ACD3 / 4)

1. SLACKEN ALL BOLTS ALMOST TO THE END OF THEIR THREADS
2. OFFER STEP TO ALIGN WITH THE OUTRIGGERS
3. LOOSELY FIT FRONT CLAMPS TO THE OUTRIGGER THEN REPEAT WITH THE REAR CLAMPS
4. FINGER TIGHTEN THE FRONT THEN REAR CLAMPS
5. ALIGN THE STEP ALONG THE LENGTH OF THE VEHICLE BY PULLING IN OR OUT
6. TIGHTEN ALL THE CLAMPS SECURELY
7. YOUR SIDESTEP IS INSTALLED, REPEAT FOR OTHER SIDE

