

WHEEL ARCH PROTECTORS Land Rover Discovery 1

Part Number: STC8498PM



Kit Contents:

- 6 piece set of wheel arch protectors
- Rubber finishing strips

Tools Required:

- Masking tape
- Degreaser
- Spatula
- Adhesive or Bonding Trim to Vehicle - 300ml - STC50551 – Genuine Land Rover

Important

Please read through all instructions and ensure that they are understood before undertaking fitting of the product.

Ensure that all contact areas of the mouldings are spotlessly clean and free of wax or grease.

Test the suitability of panel cleaner on an inconspicuous part of the vehicles i.e underside of the bonnet.

Ensure that the manufacturers instructions relating to adhesive application are correctly followed i.e humidity and temperature conditions.

1. Degrease the areas on the bodywork where the wheel arch protectors will be adhered.
2. Select a wheel arch to commence fitting and lay the wheel arch protectors face down on a protective surface i.e cloth
3. Apply the adhesive to the arch protector along its complete length and using the spatula spread the adhesive liberally and evenly over the entire face. Take care not to spread the adhesive over the edge of the arch protector as this may result in smearing of adhesive over the bodywork. (If accidental leakage occurs, white spirit will remove the excess adhesive from panels and arch protectors). Do NOT use panel wipe on the arch protectors.

Quality Parts and Accessories for



Triumph House, Sleaford Road, Bracebridge Heath, Lincoln LN4 2NA, England
Telephone: 01522 568000 | E-mail: customer.services@rimmerbros.com

www.rimmerbros.com

4. Moving along the wheel arch, locate the lip on the arch protector to the underneath of the wing. Gently press the arch protector onto the face of the body panel. In order to prevent the arch protector from slipping whilst adhesive sets, apply strips of masking tape across arch protector onto the bodywork.
5. Leave to bond for a minimum of 4 hours
6. Repeat instructions for the remaining 5 arch pieces

DO NOT wash the vehicle for a minimum of 24 hours.

Quality Parts and Accessories for



Triumph House, Sleaford Road, Bracebridge Heath, Lincoln LN4 2NA, England
Telephone: 01522 568000 | E-mail: customer.services@rimmerbros.com

www.rimmerbros.com

Registered in England No. 2155394