

SISA DESIGN WINDSTOP

Patented / TÜV tested

FITTING INSTRUCTIONS FOR: TRIUMPH SPITFIRE MKIII - IV - 1500

The windstop consists of the following parts:

1. Shield (polycarbonate) with frame, skirt.
2. Left + right fastening brackets;
3. Left + right insert-plate;
4. Two elastic bands with hook;

FITTING:

- Open the hood.
- Dismount the pins in the hoodframe to fit the insertplates (3) into the same place with the same pins.
- Push the fastening brackets (2) into the frame. The narrow parts into the insert-plates (3).
- Attach the hooks (4) into the brackets of safety belt in the back.
- Mark the positions of the snap-fasteners in the skirt.
- Drill with a 2mm drill two holes and attach them.
- Remove the foil from the shield.
- The windstop can stay in the car when the hood is closed.
- Start enjoying your convertible more than you have ever done!

Note: always use wet cloth to clean the shield!

