

SISA DESIGN WINDDEFLECTOR.™

Patented / TÜV tested.

Fitting instructions for: Triumph Stag T 040

The windstop consists of the following parts:

1. Shield (Polycarbonate) with frame and skirt
2. Protective plate.
3. Bracket.
4. Fastening straps.
5. Storage bag.

Fitting:

- Open the hood and the lid of the hood (A).
- Push the shield with frame and skirt (1) onto the protective plate (2) and secure both with the fastening straps (4).
- Place the windstop above the backseat with the brackets (3) onto the side paneling.
- Close the lid of the hood.
- Remove the foil from the shield.
- The windstop can stay in the car when the hood is closed.

NOTE : Always use wet clothes to clean shield.

