



- Unscrewing the shown screw and remove the cup holder at the end of the central tunnel (photo 1)
- OR
- Remove the rubber floor (photo 2)
- Position the armrest and secure with the supplied screw with an hand screwdriver. The screw must be centered in the hole (photo 3)
- Apply the self-adhesive felt disc on the screw head

LAND ROVER FREELANDER 2 - Fitting instructions  
Armrest with storage

